

## DIALITE® Color

The standard daylight 5,500 Kelvin for perfect shade taking.



### Technical Advantages of the DIALITE® Luminaires

- Two parallel energy-saving compact fluorescent tubes, except for VISION L.
- Two colours of daylight for perfect colour matching.
- Tubes are individually switchable and the 2/80 Watt types are additionally dimmable.
- Electronic operation of the tubes for flickerfree comfort light.
- Open top side of the reflector for indirect illumination and heat exhaust.
- Solid aluminium profiles with resistant epox silver-anthracite coating.

## DIALITE® Pro X electronic

The Perfect Suspended Luminaire in either symmetric or asymmetric design. Powerful 110 Watt.



### DIALITE Pro X 2/55 (a) electronic

- Versatile luminaire with 110 Watt for two illuminance levels of 2,500/5,000 Lux, 140/280 fc., switchable.
- Symmetrical or asymmetrical light exits, fitting the respective workplace.
- Flickerfree light, indirect and cool for comfortable ambience.

4

## DIALITE® Vision L electronic

Unique slim MULTIFLEX Lamp – perfect for limited table top space. Bright 36 Watt.



### DIALITE Vision L electronic

- Most versatile 1 x 36 Watt DIALITE at articulated spring arm.
- Illuminance 3,000 Lux/280 fc. at 500 mm/20".
- Possibility of directing the light by longitudinal rotation of the reflector.
- Choice of mountings to fit individual needs.
- Mobile due to removable reflector head and foldable arm.



5

# DIALITE®

Lighting and Luminaires

The Perfect Daylight for your Work



**SYSTEM® EICKHORST**

Light up your Vision!

!Check the web!  
[www.eickhorst.com](http://www.eickhorst.com)

**SYSTEM® EICKHORST**



